




Uncoated



AlTiN Coated



### Carbide Boring Bars Sharp Corner

Minimum Bore	Max. Depth	OAL	Shank ø	Uncoated Part #	AlTiN Coated Part #
.050	.150	2	1/8	<a href="#">RBB101000</a>	<a href="#">RBB101000A</a>
	.200	2	1/8	<a href="#">RBB101005</a>	<a href="#">RBB101005A</a>
	.300	2	1/8	<a href="#">RBB101010</a>	<a href="#">RBB101010A</a>
	.400	2	1/8	<a href="#">RBB101015</a>	<a href="#">RBB101015A</a>
.060	.150	2	1/8	<a href="#">RBB101020</a>	<a href="#">RBB101020A</a>
	.200	2	1/8	<a href="#">RBB101025</a>	<a href="#">RBB101025A</a>
	.300	2	1/8	<a href="#">RBB101030</a>	<a href="#">RBB101030A</a>
	.400	2	1/8	<a href="#">RBB101035</a>	<a href="#">RBB101035A</a>
	.500	2	1/8	<a href="#">RBB101040</a>	<a href="#">RBB101040A</a>
.080	.150	2	1/8	<a href="#">RBB101045</a>	<a href="#">RBB101045A</a>
	.200	2	1/8	<a href="#">RBB101050</a>	<a href="#">RBB101050A</a>
	.300	2	1/8	<a href="#">RBB101055</a>	<a href="#">RBB101055A</a>
	.400	2	1/8	<a href="#">RBB101060</a>	<a href="#">RBB101060A</a>
	.500	2	1/8	<a href="#">RBB101065</a>	<a href="#">RBB101065A</a>
	.600	2	1/8	<a href="#">RBB101070</a>	<a href="#">RBB101070A</a>
.100	.150	2	1/8	<a href="#">RBB101075</a>	<a href="#">RBB101075A</a>
	.200	2	1/8	<a href="#">RBB101080</a>	<a href="#">RBB101080A</a>
	.300	2	1/8	<a href="#">RBB101085</a>	<a href="#">RBB101085A</a>
	.400	2	1/8	<a href="#">RBB101090</a>	<a href="#">RBB101090A</a>
	.500	2	1/8	<a href="#">RBB101095</a>	<a href="#">RBB101095A</a>
	.600	2	1/8	<a href="#">RBB101100</a>	<a href="#">RBB101100A</a>
	.700	2	1/8	<a href="#">RBB101105</a>	<a href="#">RBB101105A</a>
.110	.150	2	1/8	<a href="#">RBB101110</a>	<a href="#">RBB101110A</a>
	.200	2	1/8	<a href="#">RBB101115</a>	<a href="#">RBB101115A</a>
	.300	2	1/8	<a href="#">RBB101120</a>	<a href="#">RBB101120A</a>
	.400	2	1/8	<a href="#">RBB101125</a>	<a href="#">RBB101125A</a>
	.500	2	1/8	<a href="#">RBB101130</a>	<a href="#">RBB101130A</a>
	.600	2	1/8	<a href="#">RBB101135</a>	<a href="#">RBB101135A</a>
	.700	2	1/8	<a href="#">RBB101140</a>	<a href="#">RBB101140A</a>
.120	.250	2-1/2	3/16	<a href="#">RBB101145</a>	<a href="#">RBB101145A</a>
	.350	2-1/2	3/16	<a href="#">RBB101150</a>	<a href="#">RBB101150A</a>
	.500	2-1/2	3/16	<a href="#">RBB101155</a>	<a href="#">RBB101155A</a>
	.600	2-1/2	3/16	<a href="#">RBB101160</a>	<a href="#">RBB101160A</a>
	.700	2-1/2	3/16	<a href="#">RBB101165</a>	<a href="#">RBB101165A</a>
	.800	2-1/2	3/16	<a href="#">RBB101170</a>	<a href="#">RBB101170A</a>
.140	.250	2-1/2	3/16	<a href="#">RBB101175</a>	<a href="#">RBB101175A</a>
	.400	2-1/2	3/16	<a href="#">RBB101180</a>	<a href="#">RBB101180A</a>
	.500	2-1/2	3/16	<a href="#">RBB101185</a>	<a href="#">RBB101185A</a>
	.600	2-1/2	3/16	<a href="#">RBB101190</a>	<a href="#">RBB101190A</a>
	.700	2-1/2	3/16	<a href="#">RBB101195</a>	<a href="#">RBB101195A</a>
	.750	2-1/2	3/16	<a href="#">RBB101200</a>	<a href="#">RBB101200A</a>
	.800	2-1/2	3/16	<a href="#">RBB101205</a>	<a href="#">RBB101205A</a>

